



BRINGS YOU ANOTHER *INNOVATIVE*
FIRST . . .



Available only on the...

NEW XB-21 **BasSport** *Pro* and **BasSport** *Tournament* 2+2

This Telescopic Pedestal elevates the Fish-Finder

Up to your level of Fishing!

E-Ped lets you view and operate your fish-finder while standing. And when you're ready to move, just slide it down and GO !



E-Ped at half-mast

The E-Ped can be positioned a choice of two heights and can rotate the fish-finder in either direction.



Operate Fish-finder while Standing

When retracted, the E-Ped disappears under the deck, placing the fish-finder flush into the bow panel, and providing superior aerodynamics and excellent visibility for safer high-speed operation of the boat.



Fish-finder retracts flush into bow-panel

◆ ◆ **FISHING HAS JUST BECOME A LITTLE EASIER!** ◆ ◆

E-Ped® (Electronics Pedestal) is PATENT PENDING.

© 2011

↑ E-Ped® ↓

The E-Ped is a telescopic mast that elevates the electronic fish-finder/ GPS to a convenient height above the casting deck, giving you the ability to view and operate the fish-finder effectively while fishing in a standing position. The E-Ped's ability to fully retract to below the deck level, places the fish-finder completely flush within the bow panel and provides superior aerodynamics and excellent visibility for faster and safer operation of the boat.



XB-21 BasSport *Pro* shown with 8" Electronics at the Console and 10" at the Bow.

See a VIDEO demonstration of the E-Ped at:
www.allisonboats.com



To raise the E-Ped, simply lift up on the fish-finder. Pull the knob slightly and continue to lift the unit to the top. The E-Ped's automatic locking system will hold the fish-finder in position as well as allow it to rotate side-to-side. When you are ready to move, pull the knob and the E-Ped will retract until the fish-finder is flush into the bow.

